




Lenovo IdeaCentre K410 T.V. Tuner Replacement

This guide will show how to remove the T.V. Tuner from the computer

Written By: Timothy Grebe





TOOLS:


- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Side Panel



- Lay the computer down on its side as shown.
- Remove the two 14mm screws shown. The screws are loose enough to unscrew with your hands.

Step 2




- Gently slide the side panel straight back and remove from the computer.

Step 3 — T.V. Tuner




- With your hands remove the 14mm screw that holds the cover on the back panel.
- Gently pull the flap back to expose the T.V. Tuner screw.

Step 4



- Use the Phillips #2 to remove the 8mm screw that holds the T.V. Tuner in place.

Step 5



- With moderate force, pull straight up on the chip to remove it from the computer.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-29 04:03:58 AM.